



# Spirocom Wired

---

This product is not available for sale in the  
US or Canada.



Spirocom Wired has PTT communication with wired transmission of the sound to the long range radio. The Spirocom system is built to handle the difficult conditions at a fire scene and still deliver high quality sound.

The PTT button has a slide type design for significantly easier activation and better ergonomics. A distinct "lift and hold" action gives access to the long range radio and makes it possible to use any part of the hand or even the shoulder when both hands are occupied.

A flexible speaker arm makes it possible to easy set the desired speaker position against the ear.

A quick attachment is mounted onto the visor frame of the face mask. With this attachment mounted it is quick and easy to mount the Spirocom onto the mask. The microphone cable is

mounted into the speech cone without interfering with the sealing of the mask. The batteries can be replaced with the unit still mounted on the face mask.

- Push-to-talk long range radio activation
- Ex/UL certified for use in explosive environments
- Powered with three AAA batteries
- Battery level indication and low battery indication

There are two versions:

1. Spirocom L - without Team Talk
2. Spirocom XL - with Team Talk

The Team Talk function is a voice-activated, full duplex, short range radio. Without having to push any buttons, voice communication is sent between firefighters, to minimize risks and increase the chances for a fast, successful mission. The Team Talk communication works for a small group of fire fighters moving together as a team. Each group is assigned with a "Group number" which is set on the Spirocom unit and visible on the display. Group configuration is made in advance and remembered by the Spirocom units, on the way to an incident the only required action is to start the unit.

It is possible to temporarily mute the Team Talk function.

## Technical specification

Approval : 2014/30/EU EMC

Standard : EN137

Standard (2) : Ex ia IIC T4

Frequency EU : 868 Mhz

Battery type : 3 x AAA

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies