



# Spiroline HP1

---



The Spiroline system is suitable for maintenance and rescue work in confined spaces where conventional breathing apparatus would make access difficult. It also provides a convenient way to perform decontamination procedures and search and rescue operations.

Spiroline HP is a ground-breaking innovative airline system that supplies high pressure all the way to the user.

The mobile and easy-to-use distribution panel is suitable for rapid deployment in remote locations. It consists of two connections for cylinders/air supplies and a central block with pressure gauge and warning whistle which automatically switches to the air supply with the highest pressure.

The variant with large (yellow) box has space for two short supply hoses and includes cylinder hooks to accommodate cylinders on the side of the box.

The Spiroline HP1 is delivered including "OPEN" sign and carabina hook.

The variant with large (yellow) box includes a pressure relief handle with Interspiro male

connection.

## Technical specification

Approval : 89/686/EEC Personal Protective Equipment

Approval (2) : EN 15333

Connection : 2 x G 5/8 (supply)

Connection (2) : 1 x G 5/8 (outlet)

Dimensions : 410 x 330 x 170 mm (standard box) / 520 x 450 x 210 mm (large box)

Weight : 4.9 kg (standard box) / 8.0 kg (large box)

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies