



Inposition™ positioning belt

Creates a safe work zone for users working at height

The Inposition positioning belt is designed for work positioning and prevention of falls from a height. The belt is designed to be easily integrated into Interspiro's SCBA sets QS II and Spiroguide II and to safely secure the user without the need for an additional belt.

Inposition™ positioning belt

The Inposition belt is designed to enable the user to perform work without undue discomfort and remain secure against the hazard of fall from a height.

For firefighting purposes, the use of QS II or Spiroguide II SCBA sets equipped with the Inposition belt can follow the same routines as for SCBA sets with the standard waist belt. Your current QS II or Spiroguide II SCBA sets can easily be upgraded with the Inposition belt, as its design is fully integrated in the design of Interspiro's QS II and Spiroguide II series of SCBAs apparatus.

1. Heat resistant Kevlar webbing
2. Metal quick connect buckle
3. Stainless steel adjusters
4. Two attachment D-rings
5. Pull-forward waist adjustment
6. Pouch for lanyard
7. Easy attachment to harness backframe



Approvals

The Inposition positioning belt is type tested and EC type examined (Directive 89/686/EEC) by DEKRA EXAM, Dinnendahlstrasse 9, D-44809 Bochum. Produced under supervision, Article 11B, by SGS United Kingdom Ltd., Weston-super-Mare, BS22 6WA, UK. (Notified Body 0120).

The Inposition positioning belt is tested according to both EN 137 (Respiratory protective devices) and EN 358 (Personal protective equipment for work positioning and prevention of falls from a height).

The Inposition positioning belt is designed to take up a greater load than a standard waist belt to fulfil EN 358.

Ordering information

- 33944-51 Inposition belt with pouch - Upgrade Kit
- 33944-52 Inposition belt with pouch and lanyard - Upgrade Kit
- 31801-01PB QS II Basic model for single cylinder, Euro coupling, incl. Pouch
- 31801-02PB QS II Basic model for single cylinder, Y-piece, 2 x Euro female connectors, incl. Pouch
- 96453-01 Pouch
- 34119-01 Lanyard 1.1 meter, with carabiner