



# Incurve

---



The Incurve is our newest SCBA with a unique harness developed together with firefighters - with every little detail in mind. With a minimum of textile parts, the Incurve harness is easy to clean, robust and light weight - without compromising comfort. The shoulder straps and hip belt is made of non-textile materials to prevent contamination and designed to be body shaped for excellent ergonomics.

The harness can easily be adjusted for different body sizes in four different size settings (“S”, “M”, “L”, “XL”). The selected size is clearly visible from both the front and the back. Thanks to the practical design the size adjustment can be made with the cylinder mounted and without removing the apparatus from the fire truck.

The regulator unit has a pressure gauge, warning whistle and optional extra air connection. The plug-in type regulator is durable and has proven functionality with high flow capacity maintaining the safety pressure also at an extreme rate of breathing and low cylinder pressures. The plug-in type design makes service and repairs easy to perform with short down time.

- Hip belt and shoulder straps move independently for maximum mobility
- Large rescue handle - easy to grab to drag out fire fighter in an emergency
- Open back plate for good ventilation and low weight

- Easy to handle and adjustable cylinder strap
- Multiple attachment points for accessories
- Small and light warning whistle
- Quick attachment of regulator unit

The Incurve SCBA can be combined with different face mask and breathing valve models which are presented under “Firefighting” / “Face Mask”.

The SCBA variants exclude face mask, breathing valve and cylinder.

Variants are available having a cylinder quick coupling with integrated flow restrictor between the regulator and the cylinder.

Variants are available without extra connections or with an extra connection on the breathing hose and/or extra air connection for airline supply.

The Incurve SCBA can be used in single cylinder or twin cylinder configuration. See “Accessories” below for cylinder dividng strap, T-piece and distance piece.

An optional holder to park the breathing valve when not attached to the face mask is available and listed under “Accessories” below.

## Technical specification

Air flow : 1350 l/min

Approval : PPE 2016/425

Connection : Cylinder - EN 144 / QC

Material : Heat resistant polymer backplate

Material (2) : Kevlar webbing

Standard : EN137 Type 2

Warning : Pneumatic whistle

Weight : ~ 3.6 kg (excl. mask & breathing valve)

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies