



# PAC Personal Alarm Control

---



The PAC - Personal Alarm Control unit excels at everything you've come to expect in regards to safety and is easily upgraded to most of our SCBA's out there. With features like buddy reading, PASS alarm and distress signals, safety comes first. The Bluetooth connection ensures the possibility to change settings and to download log files. It goes hand in hand with our unique concept of Easy Clean products and can easily and safely be machine washed.

The unit has an integrated motion alarm (PASS/ADSU). If no movement is detected during 20 seconds, the pre-alert activates. If the pre-alert is not deactivated within 10 seconds, the full alarm will start with the LEDs flashing and a high pitch alarm sound.

The full alarm can also be started at any time by pressing the alarm button.

The PASS/ADSU is activated with the cylinder pressure or with an activation key ("Tally key") depending on version.

Two rows with highly visible LED indicators provide cylinder pressure indication both to the user and to team members. When the low air alarm starts LEDs are flashing red and an alarm sound is activated. An optional turn-back warning can be activated which gives a warning indication when the pre-set cylinder pressure is reached.

With the backlight function it is also easy to read the mechanical pressure gauge.

The PAC is powered by a battery pack that includes three AAA-batteries.

## Technical specification

Approval : PPE 2016/425

Battery type : 3 x AAA

Connection : Bluetooth

Dimensions : 143 x 73 mm

Material : Silicone overmolded housing

Standard : EN 137

Standard (2) : EEX ia IIC T4

Weight : 409 gr incl batteries

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies