

QS S-FACE MASK WITH S-BREATHING VALVE

FIRST BREATH VERSION

- ❶ Outstanding breathing valve performance
→ **Very low breathing resistance**
- ❷ Breathing valve is activated from inner mask
→ **Instantaneous response to workload changes**
- ❸ First breath activation of positive pressure
→ **Positive pressure is always ensured**
- ❹ Breathing valve has a positive lock
→ **Secure connection of breathing valve**
- ❺ Silent operational mode
→ **Communicate without noise interference**
- ❻ Mask and Breathing valve in a compact design
→ **No protruding parts**
- ❼ Fits spectacles and communication devices
→ **Flexibility for different users and purposes**
- ❽ The mask is available in three different sizes
→ **Excellent fit for all face shapes and sizes**



QS S-FACE MASK

WITH S-BREATHING VALVE

REFERS TO PRODUCT(-S) WITH PART NO.(-S)
96300-series

FIRST BREATH VERSION

S-FACE MASK is comfortable and reliable, designed with Interspiros outstanding safety pedigree and innovative approach.

The inner mask separates inhaled and exhaled air to minimize the danger of breathing exhaled carbon dioxide.

S-BREATHING VALVE is a positive pressure valve with a secure connection to the face mask. The design of the demand valve supplies air only while inhaling, with instantaneous response to workload differences. The positive pressure is automatically activated on first breath.

Breathing apparatus from Interspiro is an investment with a long service life, when properly maintained. To simplify service and to obtain maximum product performance we recommend using our service kits, containing original spare parts necessary for preventive maintenance.

Interspiro offers training courses for users who perform day-to-day service work, as well as training for service personnel performing full maintenance programmes.

For more information about the QS product range and our other breathing protection products please visit us on the Internet.

STANDARDS

- EN 136 Class 3
- EN 137 (Complete Apparatus)

MATERIALS

Mask Body	Natural rubber or Silicone
Inner Mask	Natural rubber or Silicone
Visor	Heat resistant Polycarbonate
Breathing Valve	Heat resistant Polyamid
Membrane	Silicone

DIMENSIONS AND WEIGHT

Dimensions (h x w x d)	250 x 160 x 150 mm
Weight	0.88 kg

PERFORMANCE

Flow rate with preserved positive pressure	
Inner/outer mask	>450/>650 l/min.
Medium pressure range	5–11 bar
Static face mask pressure	2.0–3.5 mbar
Dynamic face mask pressure	0–9 mbar
Meets performance requirements of EN 137	

CONNECTION TO BREATHING HOSE

- M16 x 1

OPTIONS

- Hard coated visor
- Bypass unit
- Radio communication
- Hairnet
- Helmet clips

APPROVALS

- Complete Interspiro Breathing Apparatus
- CE 89/686/EEC

INTERSPIRO

www.interspiro.com | info@interspiro.com

NORTH & SOUTH AMERICA

INTERSPIRO Inc. www.interspiro-us.com
10225 82nd Avenue PLEASANT PRAIRIE WI 53158-5801 USA
TEL +1 262 947 9000 FAX +1 262 947 9020 E-MAIL info@interspiro-us.com

CENTRAL EUROPE

AUSTRIA
INTERSPIRO GesmbH www.interspiro.de
Sternweg 20 A-8401 ZETTLING AUSTRIA
TEL +43 (0)313 557 333 FAX +43 (0)313 557 333 22 E-MAIL info@interspiro.de

GERMANY

INTERSPIRO GmbH www.interspiro.de
Postfach 1220 D-76691 FORST/BADEN GERMANY
TEL +49 (0)7251 8030 FAX +49 (0)7251 2298 E-MAIL info@interspiro.de

SWITZERLAND

INTERSPIRO AG www.interspiro.de
Güterstraße 47 CH-4133 PRATTELN SWITZERLAND
TEL +41 61 827 99 77 FAX +41 61 827 99 70 E-MAIL info@interspiro.ch

THE NETHERLANDS & BELGIUM

INTERSPIRO BV www.interspiro.nl
Televisieweg 113 NL-1322 BD ALMERE NETHERLANDS
TEL +31 (0)36 5363103 FAX +31 (0)36 5384809 E-MAIL infobv@interspiro.com

UNITED KINGDOM & IRELAND

INTERSPIRO Ltd. www.interspiro.com
7 Hawksworth Road Central Park TELFORD Shropshire TF2 9TU UNITED KINGDOM
TEL +44 (0)1952 200 190 FAX +44 (0)1952 299 805 E-MAIL infouk@interspiro.com

SCANDINAVIA, ASIA/PACIFIC, MIDDLE EAST & EXPORT

SWEDEN

NORDIC & EXPORT SALES DIVISION www.interspiro.com
Box 10060 S-181 10 LIDINGÖ SWEDEN
TEL +46 8 636 51 00 FAX +46 8 765 48 53 E-MAIL info@interspiro.com

MALAYSIA

NORDIC & EXPORT SALES DIVISION www.interspiro.com
305 & 305A Lorong Perak Taman Melawati 53100 KUALA LUMPUR MALAYSIA
TEL +60 3 4105 8122 FAX +60 3 4105 3122 E-MAIL interspiro.asiapacific@interspiro.com