

## QS HARNESS

- ❶ Double pivot mechanism  
→ **Excellent weight distribution**
- ❷ Increased padding and wide shoulder straps  
→ **Ultimate comfort**
- ❸ Low weight  
→ **Reduced fatigue**
- ❹ Backplate with open design  
→ **Ventilation through backplate**
- ❺ "Parachute-style" shoulder buckles  
→ **Easily adjustable**
- ❻ Anatomically shaped backplate  
→ **Comfortable to wear BA set**
- ❼ Carrying handle  
→ **Easy to transport**
- ❽ Adjustable version as option  
→ **Optimal fit for all body sizes**



# QS HARNESS

REFERS TO PRODUCT(-S) WITH PART NO.(-S)  
95100-series

**QS HARNESS** is designed for ultimate comfort and to reduce fatigue. The harness is heavily padded with wide shoulder straps. Both the shoulder straps and the hip belt are equipped with pivot mechanisms in order to increase the freedom of movement and for an ergonomic weight distribution. The double pivot mechanism design reduces shoulder strain, even while performing heavy physical activities such as climbing ladders.

The harness can be used with a single cylinder, twin cylinders or a cylinder pack. Kevlar and Nylon versions are available.

Breathing apparatus from Interspiro is an investment with a long service life, when properly maintained. To simplify service and to obtain maximum product performance we recommend using our service kits, containing original spare parts necessary for preventive maintenance.

Interspiro offers training courses for users who perform day-to-day service work, as well as training for service personnel performing full maintenance programmes.

## STANDARDS

- NFPA 1981:2002 Edition (Complete Apparatus)
- EN 137 (Complete Apparatus)

## MATERIALS

- Backplate** Heat Resistant Polyamid
- Webbing** Kevlar 97% & Nomex 3% or Nylon

## DIMENSIONS AND WEIGHT

*Metal cylinder strap for single cylinder*

**Dimensions (h x w x d)** 630 x 410 x 200 mm

**Weight** 2.05 kg

*Cylinder pack version*

**Dimensions (h x w x d)** 630 x 410 x 80 mm

**Weight** 2.08 kg

*Textile cylinder strap version*

**Dimensions (h x w x d)** 630 x 410 x 80 mm

**Weight** 2.11 kg

## PERFORMANCE

Meets performance requirements of **EN 137 & NFPA 1981**

## APPROVALS

*Complete Interspiro Breathing Apparatus*

- CE 89/686/EEC
- CFR 42 NIOSH
- NFPA 1981:2002 Edition
- US Coast Guard

### CYLINDER PACK VERSION

Cylinder packs are easily mounted with a quick connect system.



### METAL CYLINDER STRAP VERSION

The metal cylinder strap fits cylinders with diameters from 140 to 183 mm.



### TEXTILE CYLINDER STRAP VERSION

Textile cylinder strap allow for flexibility in using single or twin cylinders.



# INTERSPIRO

[www.interspiro.com](http://www.interspiro.com)

## CENTRAL EUROPE

### AUSTRIA

**INTERSPIRO GesmbH** [www.interspiro.de](http://www.interspiro.de)

Feldbacher Str. 3 A-8200 GLEISDORF AUSTRIA

TEL +43 (0)311 236 133 FAX +43 (0)311 236 133 22 E-MAIL [info@interspiro.de](mailto:info@interspiro.de)

### GERMANY

**INTERSPIRO GmbH** [www.interspiro.de](http://www.interspiro.de)

Postfach 1220 D-76691 FORST/BADEN GERMANY

TEL +49 (0)7251 8030 FAX +49 (0)7251 2298 E-MAIL [info@interspiro.de](mailto:info@interspiro.de)

### SWITZERLAND

**INTERSPIRO AG** [www.interspiro.de](http://www.interspiro.de)

Güterstraße 47 CH-4133 PRATTELN SWITZERLAND

TEL +41 61 827 99 77 FAX +41 61 827 99 70 E-MAIL [info@interspiro.ch](mailto:info@interspiro.ch)

### THE NETHERLANDS & BELGIUM

**INTERSPIRO BV** [www.interspiro.nl](http://www.interspiro.nl)

Televisieweg 113 NL-1322 BD ALMERE NETHERLANDS

TEL +31 (0)36 5363103 FAX +31 (0)36 5384809 E-MAIL [info@interspiro.com](mailto:info@interspiro.com)

## NORTH & SOUTH AMERICA

**INTERSPIRO Inc.** [www.interspiro-us.com](http://www.interspiro-us.com)

10225 82nd Avenue PLEASANT PRAIRIE WI 53158-5801 USA

TEL +1 262 947 9901 FAX +1 262 947 9902 E-MAIL [sales@interspiro-us.com](mailto:sales@interspiro-us.com)

## UNITED KINGDOM & IRELAND

**INTERSPIRO Ltd.** [www.interspiro.com](http://www.interspiro.com)

7 Hawksworth Road Central Park TELFORD Shropshire TF2 9TU UNITED KINGDOM

TEL +44 (0)1952 200 190 FAX +44 (0)1952 299 805 E-MAIL [info@interspiro.com](mailto:info@interspiro.com)

## SCANDINAVIA, ASIA/PACIFIC & MIDDLE EAST

### SWEDEN

**NORDIC & EXPORT SALES DIVISION** [www.interspiro.com](http://www.interspiro.com)

Box 10060 S-181 10 LIDINGÖ SWEDEN

TEL +46 8 636 51 00 FAX +46 8 765 48 53 E-MAIL [info@interspiro.com](mailto:info@interspiro.com)

### MALAYSIA

**NORDIC & EXPORT SALES DIVISION** [www.interspiro.com](http://www.interspiro.com)

305 & 305A Lorong Perak Taman Melawati 53100 KUALA LUMPUR MALAYSIA

TEL +60 3 4105 8122 FAX +60 3 4105 3122 E-MAIL [asiapacific@interspiro.com](mailto:asiapacific@interspiro.com)