

# SERVICE AND TESTING SCHEDULE

**This schedule is valid for SCBA equipment.**

The schedule shows minimum requirements for service and testing as recommended by Interspiro.

Local requirements may differ due to regulations and environmental conditions.

In case of doubt consult your local Interspiro representative.

# APPARATUS / COMPONENT	BEFORE USE	AFTER USE	Preventive Maintenance		
			EVERY YEAR	EVERY 2 <sup>nd</sup> YEAR	EVERY 10 YEARS <sup>V</sup>
1 Breathing Apparatus	U	C I U	I II T		
2 Full Face Mask & Breathing Valve		D I			R II
3 Pressure Regulator & Warning Device					R II
a. High pressure connection O-ring(s)				R III	
b. Inlet filter				R III	
c. Medium pressure hoses	I	I			I II+IV
4 Harness		I	I		
5 Cylinder / Cylinder Pack		I	I II		
a. Cylinder			Periodic inspection in accordance with national regulations.		
b. Cylinder valve, service parts			Service is advised to be performed in the same periodic interval as cylinders.		

- U** = Short user test
- C** = Cleaning
- I** = Inspection
- D** = Disinfection
- T** = Performance test on a calibrated test unit by certified technician
- R** = Renew, service parts

*I* If necessary.

*II* Environmental conditions and frequency of use must be considered. Frequent use and/or use in aggressive environments may lead to shorter inspection/maintenance intervals.

*III* Frequency of use must be considered.

*IV* Medium pressure hoses older than 15 years (from date of manufacture) shall not be used.

*V* Applies to SCBA's delivered after January 1, 2008. For older equipment, see Product Bulletin 30095.

Part. No. 97307F01

## **INTERSPIRO**