



# Composite pack, 2 x 7.2L

---



The cylinder pack has a total volume of 14.4 L with an unlimited service life, "NLL" — Non-Limited Life. This large size cylinder pack is suitable for missions requiring extended duration time.

The cylinder pack consist of two cylinders mounted together with a pressure pipe protected inside the handle and is equipped with one cylinder valve.

Compared to the previous Spirolite 2 x 6.7 L cylinder pack, the new design has a greater air volume but the weight has been reduced by 18%

The cylinder pack design with two cylinders has the following advantages:

- Center of gravity closer to the body
- Possible to move more freely, for example lying on your back when spraying water at the roof
- Easier to drag out a fire fighter in an emergency

- Easier handling between mission since it cannot roll and is easy to place upright

The cylinder valve has a burst disc and the hand wheel is equipped with safety ratchet to prevent unintentional closing.

An optional pressure gauge is placed inside the handle.

The cylinder pack can be equipped with an optional quick coupling to the regulator unit.

## Technical specification

Approval : 2014/68/EU (PED)

Standard : EN12245

Material : Carbon fiber with Epoxy resin

Material (2) : PET inner liner

Connection : M18 x 1.5 neck thread

Service life : Unlimited, "NLL"

Working pressure : 300 bar

Test pressure : 450 bar

Breathing gas : Breathing air (EN12021)

Volume : 14.4 L

Length : 677 mm

Width : 360 mm

Thickness : 165 mm

Weight : 9.1 kg

# Accept cookies from this site

---

This website uses cookies to to improve your experience on the site. By clicking accept, you agree to our [privacy\\_policy](#) and [cookie\\_policy](#).

- Do not accept cookies
- Only accept functional cookies
- Accept all cookies